

CO2 Trigger & Cartridge use: AR 8

Adjustable Telescopic Lance



1. Remove the CO2 Trigger from the top pocket of the carry case and unscrew the lower casing off the trigger.

Please note

If you are using a non-threaded CO2 cartridge, please follow Step 2A then proceed to step 3.

If you are using a threaded CO2 cartridge, please proceed to Step 2B and continue to step 3.



- 2A. Place your non-threaded CO2 cartridge into the lower casing and firmly screw the lower casing back onto the trigger.




- 2B. Put your threaded CO2 cartridge into the trigger and then screw the CO2 cartridge tightly into place. Firmly screw the lower casing back onto the trigger as shown above.



3. Put the trigger into the lock position as shown above.



4. Remove the trigger strap from the top pocket of the carry case.



5. Next pull the top strap through the hole as shown above.